

ON TOP


ELESGO®

Puhastamise juhend

clean touch

Tänu oma tekstuurile on Elesgo puutepind praktiliselt peegeldusevaba ja sõrmejälgedeta. Selleks, et saaksite oma kergesti hooldatavat puhast puutepinda pikka aega nautida, oleme koostanud teile hooldus- ja puhastusjuhised.

Elesgo clean touch pinna struktuur



Pinna struktuur
mikroskoopilises
vaates

Elesgo clean touch pinna keemilised ja mehaanilised omadused muudavad puhastamise lihtsaks. Oluline on vältida abrasiivseid puhastusvahendeid, sest need võivad kahjustada pinna tekstuuri.

Elesgo clean touch pinna struktuur


- 1 N.õ mäe- ja nõlvemustri tõttu jõuab tavaline sõrmede rasvane kiht ainult pinnatekstuuri tippudesse ja ei saa seal kinni jääda, mistõttu ei jää sõrmejälgi.
- 2 Igapäevased plekid, nagu higi, rasv või õlid, settivad pinnatekstuuri mikrofiltritesse ja kaovad alles pärast puhastamist.

Quick / daily cleaning

For quick cleaning of everyday soiling, caused by cooking for example, please use the classic cleaning cloths (cotton, microfibre, terry cloths, etc.) in combination with commercially available multi-fat cleaner (spray bottle) consisting of water, soap, <5% anionic surfactants and possibly fragrances (please note the manufacturer's instructions). Spray the cleaning agent onto the cleaning cloth in a foamy consistency and clean the surface with a damp cloth. For hygienic reasons and to prevent marks, we always recommend cleaning the entire surface again in a second step with a clean cloth / sponge and clear water, then drying it with a towel.

Be absolutely sure to avoid abrasive cleaning agents and utensils!

Melamine foam sponges are available in almost every supermarket or hardware stores as well as online.



Intensive cleaning

For intensive cleaning, all you need is water and soap or washing-up liquid and a commercially available dirt eraser (made of melamine foam), also called a Magic-Eraser-Sponge. Please, soak the eraser with clear water and apply 2-3 drops of washing-up liquid on it. Immediately apply a foamy film to clean the surface. Then rinse the eraser with water and clean the surface again by repeatedly pulling the eraser in the same direction. Repeat this process until there is no more dirt left in the eraser. As long as there are still dirt residues in the eraser, the surface is not yet clean. In this case, repeat this process until there is no more dirt left in the eraser. As already described for everyday cleaning, you should clean the surface again with the dirt eraser and clear water then dry it with a towel.

made by **DTS**

DTS Systemoberflächen GmbH
Arnold-Dammers-Weg 2
39291 Möckern

phone: +49 (0) 39 221 978 - 0
fax: +49 (0) 39 221 978 - 97
email: zentrale@laminate.de